

Setup and control your stream easy!

1. Load TouchDirectorFull/Mini App for iPad from the Apple AppStore.
2. Connect your ATEM switcher as well your iOS device to your Ethernet network and to the Internet.
3. Create a livestream with streaming provider of your choice, copy and paste streaming address and key into the quick stream setup.
4. Choose streaming data rate and start streaming instantly!
Watch your streaming data rate, save and export a streaming protocol.

Reliable streaming is only possible if you connect ATEM Mini Pro and iPad to your router using Ethernet cables. For iPad this requires a Lightning to Ethernet adaptor.

NEW!
Livestream data monitoring



LOAD


Load TouchDirector/Mini App from the Apple AppStore



2-CONNECT

Connect your ATEM Mini switcher (your HyperDecks optional) as well your iOS device to your Ethernet network and to the Internet.

TouchDirector ATEM/Mini/Pro Connection Diagram with WorldTally integration




3-CREATE

Go to LiveSkills Remote Cloud streaming configurator

<https://liveskills.net/backend/StreamConfigurator.htm>




Copy streaming address and key from your streaming provider and paste data into streaming configurator website



or


Or copy your streaming data manually into the app and create a streaming configuration



Quick stream setup


Choose one of your saved streaming configurations

your saved streaming configurations will be stored automatically in your iCloud and will be available on all your iPads, you can share configurations with other people




4-STREAM



send livestream protocol





complete livestream protocol (stored in your i-Cloud automatically)




monitor your stream quality and protocol every stream data automatically, export it as png and send it with e-mail or messenger



watch your stream playback as a useful ad-on (we can't guarantee this function, because every stream player is different)



choose streaming bitrate (depends also on video framerate)



choose main or backup server

